



针对可穿戴和无线设备的低功耗传 感器融合算法

Low Power Sensor Fusion for Wearables and Wireless Devices

张永远 · 资深应用经理

Jelphi Zhang, Sr. AE manager



Sensor Fusion for Wearable & Wireless Devices

探索、创新、开拓

Introduction

Recent technological advances have enabled a new breed of wearable and smart devices

- Low footprint and low power microelectronic technologies
- Low power wireless communications
 - Bluetooth Low Energy

Ability to sense stimuli from the wearer or environment around them

- Movement, touch, sound, temperature, etc.
- Information gleaned from individual stimuli is limited
- Real value comes when combining stimuli to derive more complex metrics



Characteristics of Wireless Sensor Devices

Low Power

- Run off battery
- Long periods between charges

Multiple Sensors

- Inertial: Accelerometer, Gyroscope & Magnetometer
- Environmental: Temperature, Pressure & Humidity
- Health: Heart Rate

Communicate Wirelessly

- Intermittently upload data to host device
- Stream data in real-time



Wireless Sensor Devices and their Applications

Wearables

- Smartwatches and Activity Trackers
 - Activity/Fitness Tracking
 - Step Counting, Distance Travelled, Floors Climbed, Calories Burned
 - Classification
 - Heart Rate Monitoring
 - Indoor Navigation



Wireless Controllers


- Air Mice , Game/VR Controllers, TV/Media Center Remotes
 - Motion Tracking
 - 3 DoF Orientation Tracking
 - 6 DoF Positioning/Dead Reckoning
 - Gesture Recognition



Wearable and Wireless Sensor Device Architectures

Sensor Hub

- Single μ P/ μ C captures data from multiple sensors
- Processes data
- Communicates with host device via wireless interface
- Writes information to local storage or display
- Data Sharing Options:
 - Stream raw or processed data to host in real time across wireless interface
 - Write raw or processed to local storage for later transmission to host
 - Display locally on device




Sensor Fusion Processing Options

On Host Device or In the Cloud

- Pros:
 - Low footprint hardware architecture
 - Low cost
- Cons:
 - Generates a lot of raw sensor data to transmit/store
 - Requires high wireless bandwidth and power usage
 - Information not available to user locally on device

On Wearable Device

- Pros:
 - Allows raw data to be analyzed, combined and decimated before transmission/storage
 - Lowers required wireless bandwidth and power usage
 - Information available to user locally on device
- Cons:
 - High footprint hardware architecture
 - Higher cost






Overview of Sensor Fusion Algorithms


Sensor Fusion Algorithms

Attitude and Heading Reference System (AHRS)


- Fuses data from multiple sensors:
 - Gyroscope: Detects rotation (no absolute orientation reference)
 - Accelerometer: Detects acceleration/gravity (tilt reference)
 - Magnetometer: Detects direction of geomagnetic field (heading reference)
- Combining this information we can work out and track the absolute orientation and movement



Raw vs. Fused Sensor Data



- Data from each individual sensor plotted independently (in relative frame of reference)
- Difficult to make sense of what is going on




- Data from individual sensors combined to plot orientation (in absolute frame of reference)
- Much better overall idea of what is going on

Sensor Fusion Algorithms

Complementary Filtering

- Combines data from multiple sensors:
 - High-pass filtered gyroscope data
 - Tracks rapid rotations
 - Low-pass filtered accelerometer & magnetometer data
 - Tilt and heading references
- Susceptible to sensor distortions



Kalman Filtering

- Models expected behavior
- Compensates for inconsistencies between sensors
- More complex and computationally demanding



SmartFusion™ Library

探索、创新、开拓


SmartFusion™ Library

ARM Cortex-M0 ANSI C Library

Includes toolbox of functionality:

- Calibration of MEMS sensor data to compensate for distortions
- Processing, integration and decimation of data from various types of sensor
- Fusion of data from 3D inertial and magnetic sensors

Provided free of charge for designs using Dialog Semiconductor SmartBond™ Bluetooth Low Energy SoCs



SmartFusion™ Library – Sensor Calibration


Static Calibration Routines

- Application of externally derived calibration coefficients
- Applies 3x3 matrix and offset:

$$\begin{bmatrix} v_x \\ v_y \\ v_z \end{bmatrix} = \begin{bmatrix} m_{xx} & m_{xy} & m_{xz} \\ m_{yx} & m_{yy} & m_{yz} \\ m_{zx} & m_{zy} & m_{zz} \end{bmatrix} \begin{bmatrix} u_x \\ u_y \\ u_z \end{bmatrix} + \begin{bmatrix} o_x \\ o_y \\ o_z \end{bmatrix}$$

Automatic Calibration

- Calculates and compensates for offset, scaling and spherical distortions at runtime
- Hard and soft-iron magnetometer distortions
- Gyro drift compensation and noise gating



SmartFusion™ Library – Sensor Fusion

Integration Engine

- Integrates multiple samples of high rate sensor data over given period
- Decimates quantity of sensor data - Minimizes wireless bandwidth requirements and power consumption
- No loss of accuracy - Tracks movements more precisely and minimizes drift



Attitude and Heading Reference System (AHRS)

- Novel computationally efficient algorithm
- Utilizes quaternion geometry
- Avoids numerical issues (gimbal lock)
- Low latency
- Supports different sensor combinations in various 3, 6 & 9 DoF configurations

Mode	Degrees of Freedom	Gyroscope	Accelerometer	Magnetometer	Supported
Gyroscope Only (G)	3	✓	✗	✗	✓
Gyroscope + Accelerometer (GA)	6	✓	✓	✗	✓
Gyroscope + Magnetometer (GM)	6	✓	✗	✓	✗
Accelerometer + Magnetometer (AM)	6	✗	✓	✓	✓
Gyroscope + Accelerometer + Magnetometer (GAM)	9	✓	✓	✓	✓

SmartFusion™ Library – Software Integration



Simple/Flexible API

- Modular
 - Use and combine only set of components suitable for application
 - Each module has it's own instance/parameter structure and set of functions
- Tunable
 - Module parameters allow algorithms to be tuned according to specific hardware characteristics and application requirements

```
typedef struct cal_instance_str {  
    cal_mode mode;      /**< Calibration mode */  
    cal_params params;  /**< Calibration parameters */  
} cal_instance;  
  
void cal_init(cal_instance *instance);  
  
void cal_process(cal_instance *instance);
```

Lifecycle

1. Instantiate module instance structure
2. Initialize module
 - a) Set pointers to input/output data
 - b) Set module parameters
 - c) Call 'init' function (if it exists)
3. Process Data
 - a) Update input data
 - b) Call 'update'/'process' function

```
typedef struct {  
    SmartFusionAHRS_controls controls;  
    vect *g_vec_ptr;  /**< Pointer to the gyroscope vector */  
    vect *m_vec_ptr;  /**< Pointer to the magnetometer vector */  
    vect *a_vec_ptr;  /**< Pointer to the accelerometer vector */  
    fix g_scale;      /**< Gyroscope scaling factor */  
    fix beta_a;       /**< Parameter controlling relative weight of  
                      accelerometer data */  
    fix beta_m;       /**< Parameter controlling relative weight of  
                      magnetometer data */  
    quat q;           /**< Current estimate of the orientation */  
} SmartFusionAHRS_param;  
  
void SmartFusionAHRS_update(SmartFusionAHRS_param *p);
```



The SmartFusion™ Advantage


探索、创新、开拓

The SmartFusion™ Advantage



ARM Cortex-M0 C Library

- Designed from scratch to be as efficient as possible:
 - Smart and efficient algorithms
 - Optimized fixed point implementation (does not use floating point emulation)
 - No dependencies on external runtime libraries
- Low latency/high data rate
- Flexible/Scalable
- Processing requirements: <0.5 MCPS @ 100 Hz ODR
- Memory requirements: 5 kB
- Low Cost
 - Eliminates software licensing costs
 - Able to run on the least complex and lowest cost h/w platforms available





The SmartFusion™ Advantage

Novel approach combines the best characteristics of other approaches:

- High accuracy/performance
- Low bandwidth
- Low footprint
- Hits power efficiency sweet spot

When combined with SmartBond™
Bluetooth Low Energy SoCs

- Enables the most power efficient and low cost sensor fusion solutions on the market
- DA14583 IoT Sensor uses just 1.7 mA!






SmartFusion™ Hardware Platforms & Development Kits

探索、创新、开拓

SmartFusion™ Hardware Platforms

Dialog Semiconductor SmartBond™ Bluetooth Low Energy SoCs:

- DA1458x – World's smallest, lowest power and most integrated Bluetooth Low Energy SoC
 - Beacons & Proximity, Health & Fitness, HID, Smart Home
- DA1468x - Highest integration, flexibility and security
 - Wearables, Virtual Reality, Smart Home, Apple HomeKit, HID, Other rechargeable devices



SmartFusion™ Development Kits




DA14583 IoT Sensor Development Kit

- Bosch BMI160: 6-axis inertial measurement unit
- Bosch BMM150: 3-axis geomagnetic field sensor
- Bosch BME280: Integrated environmental unit (pressure, temperature and humidity)



DA14681 Wearable Development Kit

- Activity Tracking (using same set of sensors as above)
- Heart Rate Monitor
- Capacitive touch sensor
- NFC
- Haptic motor



SmartFusion™ Development Kits

DA14585 15DOF IoT Sensor Development Kit

- 6-axis inertial measurement unit
 - TDK Invensense ICM42605 (mounted)
 - Bosch BMI160 supported
- 3-axis geomagnetic field sensor
 - AKM AK09915C (mounted)
 - Bosch BMM150 supported
- Integrated environmental unit
 - Bosch BME680 (mounted to measure temperature, humidity, pressure, gas)
- Light, Sound
 - VCNL4010 Proximity IR & ALS Sensor
 - SPK038HT4H digital microphone



#BluetoothAsia2018#



- Alexa Voice Command
Sensor reading and
actuator control
- IFTTT Support
- Smartphone or
Raspberry Pi Cloud
Gateway support
- Location support



谢谢

Thank you!

